Lessons learned from RILEM TC MRP round-robin testing of concrete and mortar rheology in Bethune France, May 2018

Yannick Vanhove, Dimitri Feys, Mohammed Sonebi, Chafika Djelal, Sofiane Amziane, Khadija El Cheikh, Faber Fabbris, Shirin Fataei, Markus Greim, Irina Ivanova, Helena Keller, Kamal Khayat, Laurent Libessart, Viktor Mechtcherine, Ivan Navarrete, Arnaud Perrot, Egor Secrieru



Concrete rheometer Round-Robin tests executed in 2000 and 2003.

Main findings:

- Rheometers do not measure the same values, with up to a factor 2 difference in results
- Rheometers "rank" mixtures similarly in terms of yield stress and plastic viscosity.

What has changed?

- More flowable mixtures
- Different rheometers
- Interest in different properties
- Better knowledge on measurement procedures and errors



An Old Team






A New Team





ICAR (4): Vane

Flow curve (4) Static Yield stress (2) Interface Rheometry (1)



Viskomat XL: Vane

Flow curve Static Yield stress



eBT-V: Vane

Flow curve Static Yield stress



Rheometers: Bulk properties


Rheocad: Vane / Helix

Flow curve (Vane / Helix) Static Yield stress (Vane) 4SCC: Mixer / Mk-II


Flow curve

Plate test

Static Yield stress evolution with time







Rheometers: Interface properties

Sliper

Interface tool for ICAR

Interface

Interface

Plane/Plane tribometer

Friction at interface









Targeted Mixtures

Concrete 1: SCC Concrete 2: SCC Concrete 3: SCC Reference Lower Yield Stress Higher Viscosity SF = 600 mm / VF = 20 s SF = 700 mm / VF = 5 s SF = 550 mm / VF > 30 s

Concrete 4: Flowable Concrete 5: Flowable

Less Powder Higher Yield Stress SF = 600 mm / VF = 20 s SF = 400 mm / Slump = 230mm

Mortar 1: Mortar 2: Mortar 3: Reference Higher Viscosity Higher Yield Stress SF = 750 mm / VF = 3 s SF = 650 mm / VF = 5 s SF = 550 mm / VF = 3 s



*No conventional mixtures were evaluated

Need equipment: local, shipped, transported

Need concrete: preferred single batch, state-of-the-art producer, open to demands from the team

Need space and people: international collaborators, local helping hands

Need sponsors: industrial and academic, (inter)national and local

Need organizers: a team who can do all the legwork to make the RRT successful. Thanks to U. Artois: Yannick Vanhove and Chafika Djelal.



RRT Goal: Compare Rheometers

What do you want to measure?

- Flow curves
- Structural build-up
- Interface properties

Scope?

- Variety of mixtures, multiple measurements per mixture
- Maintain reliability and validity of the measurements

Outcome?

- Comparing rheometer results
- Interpretation of findings


The little details that matter:

- Batch uniformity
- Matching procedures and measuring protocols
- Precise assignment of tasks
- Timing of events
- Agreement on analysis procedure
- Common statements towards interpretation



Need to stay as objective as possible:

Reference values determined based on complex weighed average procedure






Strong correlations between rheometer values and the baseline.

Differences up to a factor 2 observed.

Attributed most likely to calibration settings in torque and rotational velocity.





All rheometers have similar deviations around best-fitting curve with baseline.

Differences in deviations depend on mix design:

- YS: coarse aggregate and YS/PV
- PV: magnitude of PV

A more extensive measuring procedure can lead to excessive shear-induced particle migration, compromising the assessment of rheology of concrete

	Rel. St. Dev. ∆ YS	Rel. St. Dev. Δ PV
ICAR 1	13.6	4.1
ICAR 2	11.3	3.5
ICAR 3	12.2	3.8
Viskomat XL	14.7	4.5
eBT-V	16.0	4.7
Rheocad	10.1	4.8

	St. Dev. Δ YS	St. Dev. ∆ PV
Concrete 1	17.7	4.1
Concrete 2	7.5	3.0
Concrete 3	11.4	9.3
Concrete 4	18.7	5.0
Concrete 5	20.7	1.3
Mortar 1	7.2	2.1
Mortar 2	5.4	2.0
Mortar 3	13.9	2.4




Structural Build-up Analysis

Static yield stress measurements Rheometer test + Flow curves: Dynamic yield stress = static yield stress with no rest 10 minutes 40 minutes Time (min) 2 measurements **Plate tests** 5 minutes ----- Continuous measurements------Time (min)



Extra point in assessment of structural build-up is beneficial

A_{thix} compared to averages varies between 0.72 and 1.29



Three thixotropy indices were evaluated

- A_{thix} (slope of static yield stress with time)
- t_c (time to double initial static yield stress)
- Coupled effect (initial yield stress x slope with time)

All indices showed similar trends

Attention should be paid to

- measuring procedure (e.g number of data points)
- data acquisition (e.g. capture points before maximum)
- disturbances (e.g. vibrations, bleeding)



Calibration:

Either use a reference material, or a simple torque meter, to perform an initial calibration of the equipment. Some differences are most likely attributed to this issue.

Enhanced Scope:

Find a compromise between maximizing validity of the measurements and more variability in concrete mixture types. Evaluate other mixtures: high yield stress, rapid stiffening Evaluate other rheometers

Reproducibility:

No repeat measurements performed



Communication:

Don't wait until the last day/hour/minute to decide on measuring protocols, mixtures types, ...

Learn-on-the-fly:

Although some results were quickly revised during the campaign, a detailed analysis of some data may have been useful to discover some concerns encountered during the analysis phase.

E.g.: Influence of measuring duration on flow curves Inclusion of third data point for structural build-up



Thank You

